




hacking
fingerprint recognition systems
(can I buy you a beer)

starbug@berlin.ccc.de

overview


- introduction
- collecting fingerprint data
- attacking the communication
- attacking the templates
- attacks using the sensor

parts of biometric systems



parts of biometric systems

parts of biometric systems - types of attacks




parts of biometric systems

- attacking the data
 - communication data (1)
 - reference data (2)
- attacking the software (3)
 - matcher
 - threshold
- attacks using the sensor (4)

23. Chaos Communication Congress


skin



profile of the finger


23. Chaos Communication Congress

skin




profile of the finger

sensors




capacitive sensor



optical sensor


23. Chaos Communication Congress

skin




profile of the finger

sensors



capacitive sensor




optical sensor

features



minutias



sweat pores

23. Chaos Communication Congress

collecting the data

visualisation of latent prints on glossy surfaces

- coloured or magnetic powder
- cyanoacrylate
- vacuum metal deposition



visualisation with coloured powder



visualisation with cyanoacrylate



visualisation with sputtered gold

visualisation of latent prints on paper

- amino acid indicator
 - Ninhydrin
 - Iodide

- thermal decomposition of grease



visualisation with
Ninhydrin



visualisation of grease

23. Chaos Communication Congress

sniffing the communication

- Hardware
 - USB-Agent / USB Tracker
 - directly connected to the sensor
 - GNU-Radio



USB-Agent

www.hitex.com

- Software
 - usbsnoop
 - sniffusb
 - usbmon

USBLog1

364 packets USB\Vid_0681&Pid_0005&Rev_0210&Ml_00

*	S...	Dir	E...	Time	Function	Data	Result
+	47	???	down	n/a	42.060	BULK_OR_INTE...	-
+	47	???	up	n/a	42.080	BULK_OR_INTE...	5a ac 5b a9 aa ab a7 ad 0x00000000
+	48	???	down	n/a	42.080	BULK_OR_INTE...	-
+	48	???	up	n/a	42.090	BULK_OR_INTE...	af af ad ad ac ae af 0x00000000

URB Header (length: 72)
SequenceNumber: 48
Function: 0009 (BULK_OR_INTERRUPT_TRANSFER)
TransferFlags: 0x00000001

TransferBuffer: 0x00001000 (4096) length

```
0000: af af af ad ad ac ae af ac 00 ad af ad af b1 ae
0010: af ad af ae ad 00 00 00 af ac ae b0 00 b0 af ae
0020: a8 ae ab a7 a4 9e a8 a9 9f a6 00 a4 00 9c 00 a2
0030: a3 00 02 01 ae ac b1 ae ae b3 ad ad b1 b0 a4 81
0040: 7b 8f 9b 97 a8 ac ad b0 ae ae ae b0 ac ae b0 b0
0050: ab a5 af ad ae b0 ab ac 9d 9d a8 a5 9b a7 aa ee
0060: ab b0 ab af aa ac ae b1 ac aa ac ab a7 9a a5 9f
0070: a2 ab ac b1 a8 ae b1 b0 ac ae ad af b1 af b0 b0
0080: ae ac b1 b1 af ac ad b0 b0 ad 99 9f af ad ac af
0090: af ac ab ae ad ad a9 a5 a8 a6 a8 ae ad ad b0 af
00a0: ad ae b2 ac ad ac a6 ad ab ad a9 ac ae ab ab a9
00b0: a6 ab 00 a9 ae a9 9e aa a9 a6 9c ac ab ad ad a9
00c0: ac ae ac 9b 78 a1 9c a2 a2 a9 ad a1 ad b0 ae ae
00d0: af aa ad ae b0 ac aa ac ac ae ac ac af ad ad af
00e0: aa af af af ae ad ac ae af ad 00 ac ae b1 b0 b1
00f0: ae ae ae ae ae ae 00 00 00 af ad ae b0 00 b0 af
0100: af af b0 ac ae a6 9a a8 84 af ae 00 ad 00 a7 00
0110: a5 a4 00 02 01 a7 ab b0 ae ae b3 af ad b0 ae a5
0120: 89 85 99 a9 a2 97 aa ad b0 ae ad ae b0 ac ae b0
0130: b0 ad ad ae ae ab ad ab af ab a7 ad a8 ae a8 ad
0140: a4 a3 b0 ab ae aa ad ae b0 ae af ae ac ad ac a3
0150: a5 9f a0 aa b1 ae ad b0 b1 ad ae ad af b2 af b0
0160: b0 ae ae b2 b1 b0 ad ad b0 b1 af ab a9 a9 ac ad
```


USB Devices

VID/PID	Snooper i...	Description
USB\ROOT_HUB\USB\OTHER_ID	-	USB-Root-Hub
USB\ROOT_HUB\USB\OTHER_ID	-	USB-Root-Hub
USB\ROOT_HUB\USB\OTHER_ID	-	USB-Root-Hub
USB\Vid_0451&Pid_2036&Rev_0101...	-	Standard-USB-Hub
USB\Vid_0483&Pid_1307&Rev_0170...	-	USB-Massenspeicher
USB\Vid_05ac&Pid_1300&Rev_1001...	-	USB-Massenspeicher
USB\Vid_05e3&Pid_0100&Rev_0100...	-	FingerChip with Genesys driver
USB\Vid_05e3&Pid_0100&Rev_0100...	-	USB Device
USB\Vid_0681&Pid_0005&Rev_0210...	Installed	ID Mouse Sensordevice
USB\Vid_0681&Pid_0005&Rev_0210...	-	ID Mouse Sensordevice
USB\Vid_0681&Pid_0005&Rev_0210...	-	USB-HID (Human Interface Device)
USB\Vid_0681&Pid_0005&Rev_0210...	-	USB-HID (Human Interface Device)
USB\Vid_0681&Pid_0005&Rev_0210...	-	USB-Verbundergerät
USB\Vid_0681&Pid_0005&Rev_0210...	-	USB-Verbundergerät
USB\Vid_0681&Pid_0005&Rev_0210...	-	USB-Verbundergerät
USB\Vid_06a5&Pid_d001&Rev_0100...	-	Panasonic Authenticam
USB\Vid_06a5&Pid_d001&Rev_0100...	-	USB Device
USB\Vid_06a5&Pid_d001&Rev_0100...	-	Panasonic Authenticam

usbsnoop

data analysis

- collecting public information
- analysing the sensor
- type of data
 - raw vs. templates
- encryption
- header
 - timestamps
 - checksums




sniffing the data @ thinkpad sensor

- direct sniffing not possible
 - hardware: built-in sensor
 - software: encrypted data (TPM?)
- external version of the sensor



external IBM sensor



USB-sniff of the Thinkpad sensor



templates

- localisation
 - in the filesystem (filemon)
 - in the registry (regmon)

- analysing
 - template to user correlation
 - used algorithms
 - checksums
 - raw images

23. Chaos Communication Congress

templates @ thinkpad sensor

ctlntr.exe:4068	QueryValue	HKLM\SOFTWARE\Protector Suite QL\1.0\DeviceBio
ctlntr.exe:4068	QueryValue	HKLM\SOFTWARE\policies\fingerprint\convenientMode
winlogon.exe:684	QueryValue	HKLM\SYSTEM\ControlSet001\Control\Nls\Locale\00000407
winlogon.exe:684	QueryValue	HKLM\SYSTEM\ControlSet001\Control\Nls\Language Groups\1
winlogon.exe:684	OpenKey	HKLM\SOFTWARE\Virtual Token\Passport\2.0\LocalPassport
winlogon.exe:684	QueryKey	HKLM\SOFTWARE\Virtual Token\Passport\2.0\LocalPassport
winlogon.exe:684	Enumerate...	HKLM\SOFTWARE\Virtual Token\Passport\2.0\LocalPassport
winlogon.exe:684	CloseKey	HKLM\SOFTWARE\Virtual Token\Passport\2.0\LocalPassport
winlogon.exe:684	OpenKey	HKLM\System\CurrentControlSet\Control\ComputerName
winlogon.exe:684	OpenKey	HKLM\System\CurrentControlSet\Control\ComputerName\ActiveC

RegMon output of the enrolment


- HKEY_LOCAL_MACHINE\SOFTWARE\Virtual Token\Passport\2.0
 - \LocalPassport\User <Username>
 - \LocalPassportBio
- C:\WINDOWS\system32\config\SOFTWARE
- template starts with: 00 13 48 5b [01 02]

23. Chaos Communication Congress

attacking the communication

attacking the communication

- replaying sniffed packages



- inserting self-generated data
 - analyse template data
 - attacking the software

23. Chaos Communication Congress

attacking the templates

attacking the templates

- adding or deleting a template
- two people matching one template
- changing template to person correlation
- attacking the software using a manipulated template

attacking the templates @ thinkpad sensor

- read the template in the registry
- add your own fingerprint to an existing template
- write back to the registry (biometric worm)

23. Chaos Communication Congress

attacks using the sensor

latent prints 1

- reactivating latent prints on touch sensors
 - capacitive: aspirate, graphite
 - optical: coloured powder
- countermeasures
 - checking minutia position of the last login



reactivating latent prints

latent prints 2

- using latent prints (not on the sensor)
 - graphite or coloured powder on adhesive tape


- not for sweeping sensors



graphite powder on adhesive tape

making a dummy finger

- gelatine, silicone
- wood glue



making a dummy finger


- enhancing with graphite spray

making a dummy fingers @ thinkpad sensor

- etching an optical PCB
- aluminium foil on adhesive tape
- transfer the fingerprint onto the foil



etched PCB



dummy finger

life check

- pulse
 - IR illuminated bloodstream
 - deformation of the ridges
- property of the skin
 - electrical and thermal conductivity
 - colour
- absorption of the blood
- sweat

preventing the recognition

- superglue
- hard work :)
- etching
- scorching
- remove with emery paper
- transplantation



normal fingerprint



superglued fingerprint



transplanted fingertips

hacked sensors (systems)

- capacitive
 - Infineon (Siemens ID mouse)
 - UPEK (IBM Thinkpads)
- optical
 - Dermalog
 - U.are.U (Microsoft)
 - Identix
- thermal
 - Atmel (ekey, iPAQ)
- electrical
 - Authentec (Medion)

conclusion

- latent prints left on nearly every surface
- prints are easy to collect
- nearly all tested systems could be fooled with home-made dummy finger
- fall-back passwords still needed

- **Don't use fingerprint recognition systems for security relevant applications!**

Thank you.

starbug@berlin.ccc.de

23. Chaos Communication Congress

